

cue
boxes

CABINET STYLE RECESSED



INSTALLING

1. Using a studfinder, locate stud placement prior to cutting out drywall if connecting unit to stud(s)
2. Cut hole into drywall approximately 14 1/8" wide x 18 1/8" high.
3. Fit unit into opening and secure to (1) or both studs. Only (1) is necessary.
4. If studs are not standard placement, run a horizontal stud connecting to left and right studs for additional support.
5. If using contractor grade drywall adhesives, simply place adhesive on the back of the flange prior to inserting unit.

